

Reverse engineering IDA

Chanung Pak


koha@korea.ac.kr

- Created by Ilfak Guilfanov
- Founder and CEO of Hex-Rays
- Premier disassembly tool available today
 - Interactive (IDCScript, IDAPython)
 - Many platforms supported (Multi-processor)
 - Highly extensible (Plug-in)



- Related manual
 - "The IDA Pro book" by Chris Eagle
 - "Reverse Engineering Code with IDA Pro" by Dan Kaminsky

- IDA (Interactive DisAssembler)
 - https://www.hex-rays.com/founded by IlfakGuilfanov
 - Two editions: IDA Professional, IDA Starter
- IDA (Disassembler & Debugger) + Hex-Rays Decompiler




- Key Features: Disassembler
 - Supported processors https://www.hex-rays.com/products/ida/processors.shtml
 - Various executable file formats, Code graphing
 - SDK, Plug-in, IDC Script, IDAPython
- Key Features: Debugger

Target Platform	IDA runs on Windows	IDA runs on Linux	IDA runs on Mac OS X	Notes
Windows 32/64 bits	Local/Remote	Remote	Remote	
Linux 32/64 bits	Remote	Local/Remote	Remote	On 64 bits - remote only
OS X 32/64 bits	Remote	Remote	Local/Remote	
Bochs	Bochs Emulator	Bochs Emulator	Bochs Emulator	
GDB Server	GDB Server	GDB Server	GDB Server	x86, ARM, PowerPC, MIPS
WinDBG 32/64 bits	Remote	-	-	User-mode, Kernel-mode
Android (Dalvik)	Remote	Remote	Remote	DEX bytecode, Source

Evaluation & Freeware versions


- https://www.hex-rays.com/products/ida/support/download.shtml
- Freeware: v5.0
- Evaluation version v6.9
 - Only supports INTEL 80x86 & ARM family
 - Only supports PE/ELF/Mach-O formats
 - Time limited (30 min?)
 - Save is disabled




References

- "The IDA Pro Book 2nd Edition" by Chris Eagle
- "Reverse Engineering Code with IDA Pro" by Dan Kaminsky
- https://www.hex-rays.com/products/ida/support/idadoc/index.shtml
- http://www.hexblog.com/








Launching IDA









Launching IDA




Launching IDA - Executable File






Launching IDA -Executable File







Launching IDA -Executable File




Launching IDA -Binary File









Launching IDA -Binary File




Launching IDA -Binary File




- IDA Database Files
 - 4 Components: id0, id1, nam, til
 - Hotkey 'Ctrl + W'
 - Pack file: idb (IDA Database)
 - Save options
 - Pack database –Store or Deflate
 - Lack of the 'undo' feature









IDA Desktop




- IDA View -Disassembly Window
 - Graph view -'Space bar'




- IDA View -Disassembly Window
 - Text view-'Space bar'



- IDA View -Disassembly Window
 - Proximity browser (from IDA v6.2) ' '
 - Call graph of a Program
 - Supported layouts: Tree, Circle, Polar, Radial tree, Digraph




Hex View




Functions Window

'Shift + F3'


Flag	Description
R	Function returns to caller
F	Far function
L	Library function
S	Static function
В	EBP based frame
Т	Function has type information
=	Frame pointer is equal to the initial stack pointer




Imports Window




Exports





- Names Window -'Shift + F4'
 - Variables
 - Labels
 - Imported functions
 - Exported functions
 - ASCII strings
 - **-**




Strings Window -'Shift + F12'









Enumerations Window -'Shift + F10'







Structure Window -'Shift + F9'




Segments / Segment Registers - 'Shift + F7', 'Shift + F8'



List of Applied Library Modules (%IDADIR%\sig) -'Shift + F5'




Loaded Type Libraries (%IDADIR%\til) -'Shift + F11'



- [Reference] Names Representation
 - https://www.hex-rays.com/products/ida/support/idadoc/609.shtml

Name Prefix	Description		
sub_	instruction, subroutine start (function)		
locret_	Address of 'return' instruction		
loc_	instruction address (label)		
off_	data, contains offset value		
seg_	data, contains segment address value		
asc_	data, ASCII string		
byte_	data, byte		
word_	data, 16-bits		
dword_	data, 32-bits		
qword_	data, 64-bits		
xmmword_	data, 128-bits		
flt_	floating point data, 32-bits		
dbl_	floating point data, 64-bits		
tbyte_	floating point data, 80-bits		
stru_	structure		
custdata_	custom data type		
algn_	alignment directive		
unk_	unexplored byte		

Navigator




Click Navigation


Previous -'ESC'

Jump to Address


Hotkey -'g'




Jump operations



- Stack Frames -'Ctrl + K'
 - Double click -'var_*' or 'arg_*'





- Stack Frames -'Ctrl + K'
 - Double click -'var_*' or 'arg_*'




- Searching Databases
 - Text Search -'Alt + T'


Binary Search -'Alt + B'







- Names and Naming -'N'
 - Parameters and Local Variables
 - Named Location
 - Register Names











Commenting


Anterior lines -'Ins'



- Code Transformations
 - Disassembly line display options





- Code Transformations
 - Formatting instruction operands



Code Transformations


Manipulating functions






- Code Transformations
 - Converting code to data -'D'
 - Converting data to code -'C'





- Code Transformations
 - Converting code to data -'D'
 - Converting data to code -'C'






Data Transformations

- Working with Strings -'Alt + A'
 - ASCII -'A'


```
01001580 ; const WCHAR aColors
01001580 aColors:
                                                  ; DATA XREF: CalcWndProc(HWND
01001580
                         unicode 0, <colors>,0
0100158E
                         align 10h
01001590 ; CHAR byte 1001590[]
01001590 byte 1001590
                         db 68h
                                                  ; DATA XREF: HtmlHelpW(x,x,x,x)
01001591
                         db 68h ; h
01001592
                         db 63h ; c
01001593
                         db 74h : t
01001594
                         db 72h ; r
01001595
                             6Ch ; 1
01001596
                            2Eh ; .
01001597
                            6Fh ; o
01001598
                            63h ; c
01001599
                             78h ; x
0100159A
                         db
                               0
0100159B
                         align 10h
```




```
01001590 ; CHAR aHhctrl_ocx[]
01001590 aHhctrl_ocx db 'hhctrl.ocx',0 ;
0100159B align 10h
010015A0 ; CHAR SubKey[]
010015A0 SubKey db 'CLSID\{ADB880A6-D8FF-
010015A0 ; CHAR ValueName[4]
010015DC ; CHAR ValueName db 4 dup(0) ;
```

Data Transformations

Specifying arrays -'*'







Code Cross-References

```
text:010124A4
                                       eax, 10Bh
text: 010124A9
                               jΖ
                                       short loc 10124CA
text: 010124AB
                                       eax, 20Bh
                               cmp
text:010124B0
                                       short loc 10124B7
                               jΖ
text:010124B2
                                                        ; CODE XREF: WinMainCRTStartup+1Cfj
text:010124B2 loc 10124B2:
text:010124B2
                                                        ; WinMainCRTStartup+29<sup>†</sup>j ...
text:010124B2
                               mov
                                       [ebp+hi], ebx
text:010124B5
                               cpm j
                                       short loc 10124DE
text:010124B7 ; -----
text:010124B7
text:010124B7 loc 10124B7:
                                                        ; CODE XREF: WinMainCRTStartup+3B<sup>†</sup>j
text:010124B7
                               cmp
                                       dword ptr [ecx+84h], 0Eh
text:010124BE
                               jbe
                                       short loc 10124B2
                                       eax, eax
text:010124C0
                               xor
text:010124C2
                               cmp
                                       [ecx+0F8h], ebx
text:010124C8
                               cpm j
                                       short loc 10124D8
text:010124CA : -----
text:010124CA
text:010124CA loc 10124CA:
                                                        ; CODE XREF: WinMainCRTStartup+34fj
text: 010124CA
                                       dword ptr [ecx+74h], 0Eh
                               стр
text:010124CE
                               jbe
                                       short loc 10124B2
                                       eax, eax
text:010124D0
                               xor
text:010124D2
                                       [ecx+0E8h], ebx
                               cmp
text:010124D8
text:010124D8 loc 10124D8:
                                                        ; CODE XREF: WinMainCRTStartup+53fj
text:010124D8
                                       al
                               setnz
text: 010124DB
                                       [ebp+hi], eax
                               mov
text: 010124DE
text:010124DE loc 10124DE:
                                                        ; CODE XREF: WinMainCRTStartup+40fj
                                       [ebp+ms exc.registration.TryLevel], ebx
text: 010124DE
                               mov
                                       2
text:010124E1
                               push
text:010124E3
                               call
                                       ds: imp set app type
```

Data Cross-References


```
dw 94h
text:01012E34 word 1012E34
                                                        ; DATA XREF: .text:off 1012CA8
text:01012E36
                               db 'ShellAboutW',0
                                                        ; DATA XREF: .text:0101288CTo
text:01012E42 aShell32 dll
                               db 'SHELL32.dll',0
text:01012E4E word 1012E4E
                               dw 52h
                                                        ; DATA XREF: .text:off 1012DC8
text:01012E50
                               db ' CxxFrameHandler',0
                               dw 47h
text:01012E62 word 1012E62
                                                        ; DATA XREF: .text:01012DCC o
text:01012E64
                               db ' CxxThrowException',0
text:01012E77
                               aliqn 4
                               dw 338h
                                                        ; DATA XREF: .text:01012DD0 o
text:01012E78 word 1012E78
text: 01012E7A
                               db 'wcstoul',0
text:01012E82 word 1012E82
                               dw 31Ah
                                                        ; DATA XREF: .text:01012DD410
text:01012E84
                               db 'toupper',0
                                                        ; DATA XREF: .text:01012DD8fo
text:01012E8C word 1012E8C
                               dw 326h
                               db 'weschr',0
text:01012E8E
text: 01012E95
                               align 2
                                                        ; DATA XREF: .text:01012DDC o
text:01012E96 word 1012E96
                               dw 2DEh
                               db 'memmove',0
text: 01012E98
text:01012EA0 word 1012EA0
                               dw 32Ch
                                                        ; DATA XREF: .text:01012DE0 o
text: 01012EA2
                               db 'wcslen',0
text: 01012EA9
                               align 2
text:01012EAA word 1012EAA
                               dw 22Fh
                                                        ; DATA XREF: .text:01012DE4fo
text: 01012EAC
                               db ' wcsrev',0
                               dw 0C5h
text:01012EB4 word 1012EB4
                                                        ; DATA XREF: .text:01012DE8fo
text:01012EB6
                               db ' c exit',0
text:01012EBE word 1012EBE
                               dw OF6h
                                                        ; DATA XREF: .text:01012DEC o
                               db ' exit',0
text: 01012EC0
                               dw 4Eh
                                                        ; DATA XREF: .text:01012DF0 o
text:01012EC6 word 1012EC6
text:01012EC8
                               db ' XcptFilter',0
                               dw 0C8h
                                                        ; DATA XREF: .text:01012DF4 o
text:01012ED4 word 1012ED4
                               db ' cexit',0
text:01012ED6
text:01012EDD
                               align 2
```

Cross-References Lists -'Ctrl + X'


```
text:01012E34 word 1012E34
                                 dw 94h
                                                           ; DATA KREF: .text:off 1012CA8 o
text:01012E36
                                 db 'ShellAboutW',0
                                                          ; DATA KREF: .text:0101288CTo
                                db 'SHELL32.dll',0
text:01012E42 aShell32 dll
. text: 01012E4E
                xrefs to word 1012E34
                                                                                             text:01012E50
                Direction Typ Address
                                           Text
text:01012E62
                🖼 Up o .text:off 1012CA8
                                          dd rya word 1012E34
text:01012E64
text:01012E77
text:01012E78
                                          OK.
                                                  Cancel
                                                            Search
                                                                       Help
text: 01012E7A
                Line 1 of 1
text:01012E82
                                db 'toupper',0
.text:01012E84
.text:01012E8C word 1012E8C
                                 dw 326h
                                                           ; DATA KREF: .text:01012DD8fo
                                 db 'weschr',0
.text:01012E8E
                                aliqn 2
.text:01012E95
.text:01012E96 word 1012E96
                                                          ; DATA KREF: .text:01012DDC o
                                 dw 2DEh
.text:01012E98
                                 db 'memmove',0
text:01012EA0 word 1012EA0
                                 dw 32Ch
                                                           ; DATA XREF: .text:01012DE0 o
                                db 'wcslen',0
text: 01012EA2
                                aliqn 2
text:01012EA9
.text:01012EAA word 1012EAA
                                 dw 22Fh
                                                           ; DATA KREF: .text:01012DE4 o
text: 01012EAC
                                 db ' wcsrev',0
.text:01012EB4 word 1012EB4
                                 dw 0C5h
                                                           ; DATA XREF: .text:01012DE8 o
                                 db ' c exit',0
.text:01012EB6
.text:01012EBE word 1012EBE
                                 dw OF6h
                                                          ; DATA KREF: .text:01012DECTo
.text:01012EC0
                                 db ' exit',0
                                 dw 4Eh
.text:01012EC6 word 1012EC6
                                                           ; DATA XREF: .text:01012DF0 o
text:01012EC8
                                 db ' XcptFilter',0
```

Function Calls

View -Open subviews-Function calls




Integrated Graph View




External Graphing


Flow chart -'F12'



- External Graphing
 - Function calls -'Ctrl + F12'



- External Graphing
 - Xrefsgraph to / from



Thank you for listening



koha@korea.ac.kr